


Návod na inštaláciu LGS105

► Všeobecné informácie

Je veľmi dôležité, aby ste si tieto pokyny prečítali celé a všetky obrázky si dôkladne preštudovali pred začatím inštalácie vašej LED solárnej lampy LGS900. Uchovajte tento návod pre prípad potreby v budúcnosti.

Pozor:


- Batériu nevhadzujte do ohňa. Može to zapríčiniť explóziu.
 - Neumiestňujte lampu v blízkosti ohňa ani silnému teplu, nakoľko batéria môže explodovať.
 - Neponárajte lampu do vody.
 - Nikdy sa nepozerajte priamo do svetelného zdroja a neožiarujte ním iné osoby.
 - Dodržiavajte správne bezpečnostné postupy, aby ste zabránili neželanému pádu alebo zraneniam.
 - Životnosť batérie sa skraca, ak sa pravidelne nenabíja na plnú kapacitu. To znamená, že batéria sa rýchlejšie vybíja pokiaľ nie je pravidelne plne nabitá. V prípade, že batéria už nedrží svoju kapacitu je potrebné ju vymeniť za novú s rovnakými parametrami.
- Záruka 3 roky sa nevzťahuje na životnosť samotnej batérie.**



1.	Nerezový kryt
2.	Svietidlo
3.	Prepínač
4.	Sklenený panel
5.	Batéria
6.	Púzdro batérie
7.	Hliníkový plášť

► Inštalácia

- Krok 1: Solárne svietidlo musí byť umiestnené na miesto, kde bude prijímať slnečné svetlo aspoň 8 hodín a to každý deň. Akékoľvek prekrytie, tieň alebo prekážanie prieniku svetla na solárny panel svietidla zapríčini oslabenú funkčnosť svietidla a jeho skoré znehodnotenie.
- Krok 2: Zvolené miesto pre inštaláciu nesmie byť v blízkosti svetelného zdroja, ktoré svieti vysokou intenzitou počas noci ako je napríklad lampy verejného osvetlenia, nakoľko sa solárne svietidlo bude samovoľne vypínať alebo blikať.





► Uvedenie do prevádzky

- 1) Stlačte tlačidlo do polohy "ON"
- 2) Vložte solárne svietidlo do inštaláčného otvoru.

► Výmena batérie

- Krok 1: Batéria (5) je umiestnená v púzdre pre batériu vo svietidle (6).
- Krok 2: Odskrutkujte 4 kusy skrutiek (1,2,3,4) z vrchného nerezového krytu svietidla (1). Vyberte sklenený difúzor (4).
- Krok 3: Vyberte von púzdro batérie (6)
- Krok 4: Vyberte starú batériu a vymeňte ju výhradne za identickú nabíjateľnú batériu.
(Typ batérie AA 1500mAh NI-MH)
- Krok 5: Vložte späť púzdro batérie (6) do hliníkového plášťa (7) a zaskrutkujte nerezový kryt.



► Nabíjanie batérie

- batéria sa nabíja priamo zo zabudovaného solárneho panelu na svietidle
- solárny panel potrebuje pre čo najväčšiu efektívnosť priame slnečné svetlo
- pokiaľ je solárny panel špinavý, nedokáže efektívne nabiť batériu

Distribútor:
EKONN spol. s.r.o.
Trst'any 52, 044 45 Trst'any
email: eshop@ekonn.sk tel. +421 911 921 055
www.ekoledshop.sk

Výrobca:
BestService Sp. Z o.o.
ul. Łopuszańska 95, 02-457 Warszawa
e-mail: lumax@bestservice.com.pl tel. 22 863 25 55
www.lumax.pl


Installation instruction - LGS105

► General information

It is vitally important that these instructions are read in their entirety and any illustrations studied before commencing installation of your fitting. Keep these instruction for future reference.

Attention:


- Do not dispose of battery in fire. This may result explosion.
 - Do not expose the light to fire or intense heat as battery may explode.
 - Do not immerse in water.
 - Never look directly into the source of light or shine it into another person's face.
 - Follow proper safety tips to prevent from falling off a ladder.
 - Battery life get shorter when are not full, which means that it isn't charged full after every discharge. In case of battery wear off please replace it with one with same parameters.
- 3 years warranty do not include battery.**



1.	Stainless steel panel
2.	Lamp
3.	Switch
4.	Glass panel
5.	Battery
6.	Battery housing
7.	Aluminium shell

► Installation

- Step 1: Solar light must be installed in a sunny location where they will receive at least 8 hours of sunlight each day. Any cover, shade or shadowing will affect the light solar panel to absorb sunlight and its function will be decreased.
- Krok 2: The selected location should not be near a nighttime light source such as a porch light or streetlight, as these might keep the solar light from automatically turning on.





► Operation

- 1) Turn the switch to "ON".
- 2) Put the solar light in the installation hole.

► Maintenance

- Step 1: The battery (5) is located in the Battery housing (6).
- Step 2: Remove the four screws (1,2,3,4) from the Stainless steel panel (1). Remove the Glass panel (4).
- Step 3: Take out the Battery housing (6)
- Step 4: Remove old battery, replace only with identical rechargeable battery.
(Battery size AA 1500mAh NI-MH)
- Step 5: Replace the Battery housing (6) in the Aluminium shell (7). Secure it with the four screws.



► Charge the battery

- You can charge the battery used solar panel.
- Install the solar panel at the location that can get the direct sunlight.
- The solar panel should be toward the sun. If the solar panel is dirty, it cannot charge the battery efficiently.

Distribútor:

EKONN spol. s.r.o.
Trst'any 52, 044 45 Trst'any
email: eshop@ekonn.sk tel. +421 911 921 055
www.ekoledshop.sk

Výrobca:

BestService Sp. Z o.o.
ul. Łopuszańska 95, 02-457 Warszawa
e-mail: lumax@bestservice.com.pl tel. 22 863 25 55
www.lumax.pl